



## Bedienungsanleitung

### 1. Montage

Den Wendeplattenhalter (1) auf Werkzeughalter (2) aufschrauben und mit Gabelschlüssel (3) festziehen.

### 2. Demontage

Wendeplattenhalter (1) mit Gabelschlüssel (3) im Gegenuhrzeigersinn lösen, dabei immer mit Gabelschlüssel (4) gegenhalten.

#### ACHTUNG:

Der Stahlteil ist fest mit dem Hartmetallteil verbunden und darf nicht gelöst werden (Bruchgefahr!).

## Mode d'emploi

### 1. Montage

Visser le porte-plaque (1) sur la barre porte-outil (2) et serrer avec la clé (3).

### 2. Démontage

Dévisser le porte-plaque (1) avec la clé (3) en sens inverse des aiguilles

d'une montre, en tenant toujours la barre porte-outil (2) avec la clé (4).

#### ATTENTION:

La partie acier est fixée sur la partie carbure et ne doit pas être démontée (risque de casse!).

## Operating instruction

### 1. Assembly instruction

Screw the insert holder (1) on the tool holder (2) and tighten it with the wrench (3).

### 2. Disassembly instruction

Unscrew the insert holder (1) from the tool holder (2) in counter-clockwise direction by means of wrench (3).

**Always support the tool holder (2) with wrench (4) at the same time.**

#### ATTENTION:

Steel part and carbide part are fixed together. Never try to separate them (Risk of breaking!).